


Gebrauchsanweisung für Schlagwerkuhren mit Unruh-Gangregler

Regulierspindel
Regulating spindle
Vis de réglage



Operating Instructions for Clocks with Strike and Escapement

This clock is a quality product and really should give you pleasure. Therefore, please consider carefully the following instructions:

Remove safety locks (for hammer and gong) protecting movement and gong. The key is attached inside the door and can be removed by pushing upwards.

Setting the clock

Wind up carefully and set the clock. If the clock doesn't start automatically, move the minute hand back and forth.

Timing the clock

The clock is fitted with a precisely working escapement, which has been developed for this purpose and has been exactly adjusted already in the factory.

Nevertheless, if a new timing is necessary, please turn the regulating spindle with a small screwdriver according to the symbols (see drawing).

If clock runs too slow, turn to + (plus).

If clock runs too fast, turn to - (minus).

Turning the regulating spindle to the indication (60°) corresponds to approx. 10 sec./day.

A full turn of the regulating spindle equals to approx. 1 min./day.

All clocks, except small mantel clocks (8-day-strike movement), are fitted with shut off lever at the back of the case. Turn the knob, if you want to shut off the strike.